



ACTUADOR RELAY



www.smarthouseperu.com
sopORTE@smarthouseperu.com



neocontrol
Somfy Group

Neocontrol US LLC © 2017
All rights reserved.

ENGLISH



Please, follow the device's operating instructions as indicated in this manual.



You must make sure that electrical equipment and installations are in accordance to the information on the label of this device.



Watch Out! Never open the device or any of its components. Risk of electric discharge.



Sensitive to humidity! The device must not be exposed to liquids or excess moisture.



Fragile. Handle your device carefully, avoiding impacts.



Recyclable product. Do not dispose into the environment.

This is a free guide and part of the product; therefore it cannot be sold separately, copied or duplicated without written permission from Neocontrol US LLC.

OVERVIEW

ACTUADOR RELAY is an actuator responsible for the control of two discrete circuits (on / off / push) of up to 2A.

Preferred installation in the plaster lining;
Wireless communication (radiofrequency).

COMPATIBILITY:

Compact Module Line

SAFETY AND RESPONSIBILITY

Please read this guide carefully before using the product. This product must be installed by a qualified home automation installer. The installer must comply with current standards and legislation in the country in which the product is being installed, and inform his customers of the operating and maintenance conditions of the product. Failure to comply with the instructions herein constitutes a violation to the warranty and will discharge Neocontrol of any and all liabilities.

ESPAÑOL



Siga correctamente las instrucciones del manual.



Antes de comenzar con la instalación asegure que las fuentes de alimentación sean las indicadas en la caja.



Cuidado! Nunca abra el aparato o sus componentes. riesgo de **choque eléctrico.**



Sensible a la humedad! El aparato no debe entrar en contacto con agua o ambientes excesivamente húmedos.



Producto frágil. Cuide de su dispositivo, evitando impactos.



Producto Reciclable. No descartar en residuos generales.

Este manual es gratuito y parte del producto, por lo que no se puede vender por separado, ni copiar sin el permiso por escrito de Neocontrol US LLC.

PRESENTACIÓN

ACTUADOR RELAY es un actuator responsable del mando de dos circuitos discretos (encendido / apagado / pulsa) de hasta 2A.

Instalación preferente en el forro de yeso;
Comunicación inalámbrica (radiofrecuencia).

COMPATIBILIDAD:


Línea de módulo Compact

SEGURIDAD Y RESPONSABILIDAD

Lea este manual antes de utilizar el producto. Este producto de Smart House Perú debe ser instalado por un profesional certificado de automatización residencial. Además, la persona instalando debe cumplir con las normas y legislaciones en vigor del país en el que el producto está siendo instalado, e informar a sus clientes de la operación y mantenimiento del producto. Cualquier violación a las instrucciones contenidas en este manual constituye una violación a la garantía y absuelve a Neocontrol de cualquier responsabilidad.

Para más información visite:

www.smarthouseperu.com



AUTOMATIZACIÓN
DE CASAS, DEPAS
Y OFICINAS.

